

MANUFACTURER COMPANY

Address :

Tel :

Fax :

SERVICE :

Address :

Tel :

Fax :

PRODUCT INFORMATION

TYPE : MODULATOR

BRAND :

MODEL : SDM 08

BARCODE SERIAL NO :

DELIVERY DATE/PLACE :

REPAIR TIME :

WARRANTY PERIAD : 3 YEARS

SELLER COMPANY

COMPANY NAME :

ADRESS :

PRODUCT BRAND/MODEL :

PRODUCT SERIAL NO :

INVOICE NO :

INVOICE DATE :

SALE DATE :

SELLER COMPANY

DATE

SIGNATURE

STAMP

COSTUMER NAME




8 CHANNEL DSB OFD COMPACT MODULATOR

SDM 08 USER GUIDE




Video input Level	: 1Vpp/75 ohm
Video Modulation Polarity	: Negative-AM
Video Modulation Depth	: % 83
Video S/N	: 55 dB
Audio Input Level	: -3, +3b/10K Ω
Audio Modulation Type	: FM
Audio Modulator Devlation	: %100 (40Hz - 15Khz)
Picture to Sound Ratio	: 16dB
RF Output Level	: 8 X 85dB μ V/75 Ω
RF Output Attenuation	: 10dB
Power Supply	: 140 - 240 AC (20W. SMPS)
Frequency Band (VHF-D-Hiper)	: S1- S41, C05 - C12
Frequency Band (UHF)	: C21 - C69 (Optional)
System	: PAL / BG , DK , I




M1:Quick Channel Adjustment Menu

Press OK and Right buttons together to enter The menu
Press right or left button to adjust channels in order
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu




M2:Modulator 1 Manuel Channel Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M2 sub-menu
Press right or left button to adjust channel modulator 1
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu




M3:Modulator 2 Manuel Channel Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M3 sub-menu
Press right or left button to adjust channel modulator 2
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu




M4:Modulator 3 Manuel Channel Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M4 sub-menu
Press right or left button to adjust channel modulator 3
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu




M5:Modulator 4 Manuel Channel Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M5 sub-menu
Press right or left button to adjust channel modulator 4
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu




M6:Modulator 5 Manuel Channel Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M6 sub-menu
Press right or left button to adjust channel modulator 5
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu




M7:Modulator 6 Manuel Channel Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M7 sub-menu
Press right or left button to adjust channel modulator 6
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu



M8:Modulator 7 Manuel Channel Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M8 sub-menu
Press right or left button to adjust channel modulator 7
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu



M9:Modulator 8 Manuel Channel Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M9 sub-menu
Press right or left button to adjust channel modulator 8
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu



M10:Modulators System Selection Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M10 sub-menu
Press right or left button to select modulators system(B/G, D/K, I)
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu



M11: Language Selection Adjustment

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M11 sub-menu
Press right or left button to select English or Turkish
Press OK button to save
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu



M12: Recall Factory Settings

Press OK and Right buttons together to enter The menu
Use UP or Down button to enter M12 sub-menu
Press OK button to return The factory settings
Press Up or Down button to enter next or before The sub-menu
Press OK and Right buttons together to exit from The menu